

NOTES:

- 1. INSTALLER MUST USE STRING LINES AND/OR CHAULK LINES TO KEEP PAVER BOND LINES STRAIGHT.
- 2. CONSULT AN ENGINEER FOR HEAVY VEHICULAR APPLICATIONS.
- 3. FOR VEHICULAR USE BEST PRACTICES REQUIRE HERRINGBONE OR CHEVRON PATTERN.
- 4. COMMERCIAL VEHICULAR APPLICATIONS REQUIRE THICKER PAVING UNITS.
- 5. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
- 6. DO NOT SCALE DRAWING.
- 7. THIS DRAWING IS INTENDED FOR USE BY ARCHITECTS, ENGINEERS, CONTRACTORS, CONSULTANTS AND DESIGN PROFESSIONALS FOR PLANNING PURPOSES ONLY. THIS DRAWING MAY NOT BE USED FOR CONSTRUCTION.
- 8. ALL INFORMATION CONTAINED HEREIN WAS CURRENT AT THE TIME OF DEVELOPMENT BUT MUST BE REVIEWED AND APPROVED BY THE PRODUCT MANUFACTURER TO BE CONSIDERED ACCURATE.
- CONTRACTOR'S NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info AND ENTER REFERENCE NUMBER 256-131.

INSTALLATION SYSTEMS

SAND SETTING BED ON RIGID BASE

256-131

CADdetails.com